



How to adjust a Toro Super 600

To Increase Arc



To Decrease Arc



Spray Radius Adjustment

A stream breaker screw, accessible from top of nozzle with a 1/16" hex driver, is provided to shorten radius and/or diffuse spray.

Note: To prevent a possible dry area around head when operating at low pressure, adjust stream breaker to slightly diffuse spray.

Caution

Stream breaker screw will fall into water stream if decrease adjustment is excessive. Replacement will be necessary.

To Decrease Radius

1. Rotate stream breaker screw clockwise. (See right)

To Increase Radius

1. Rotate stream breaker screw counterclockwise. (See right)

